UNIVERSAL NOTEBOOK CAR CHARGER

A

FUJITSU-SIEMENS

C-4120/C-4235/C-5130/C-5235/C-6177/C-6320/C-6330/C-6525/C-6535/C-6537/ C-6547/C-6556/C-6557/C-6577/E-5140/E-5320/E-5520/E-6520/E-6530/E-6540/E-6541/E-6550/E-6555/E-6556/E-6557/E-6570/E-6571/E-6575/E-6595/I-4187/I-4190

PenCentra – 130/200/

Point – 1600/510/S-5582/1000/1200/2300/3400/3500/500/LT/LT C-500/LT P-600

Stylistic – ST40xx/ST41xx/ST42xx

Lifebook – C2010/C2110/C2111

Sony

PCG-C1XS/PCG-505TR/PCG-505TS/PCG-505TX/PCG-505F/PCG-505FX/PCG-505G/G-505GX/PCG-SRX77/CPCG-SRX77/C/NPCG-SRX77P/CPCG-SRX77P/NPCG-SRX87/PCG-SRX871/PCG-SRX87P/PCG-SRX87P1/PCG-SRX87P2/PCG-SRX87P3/PCG-SRX87P4/PCG-SRX99Series/PCG-SRX99/PCG-SRX992/PCGSRX99K/PCG-SRX99K3/PCG-SRX99P/PCG-SRX99P2/PCG-SRX99P4/PCG-SRX99P5/PCG-VX88/PCGVX88P/PCG-VX89/PCG-VX891/PCG-VX89K/PCG-VX89K1/PCG-VX89P/PCG-VX89P1/PCG-VX89P2/PCG-VX89P3/PCG-VX88 Series/VX88 Series BackUp/VX89 Series

B

DELL

Inspiron – 3000/3200/3500/3500 D233XT/3500 D266GT/3500 D300GT/7000 D266GT/7000 D300LT/7000 Series

ACER

AcerNote – 367D/367T/390/390A/391/392/393/394/395

Anywhere – 1100LX/ 1120LX/

Extensa – 365/366D/367D/368D/390/390C/390CX/393/900/ESS3-391T

Compaq

Presario – 1000/ 1010/ 1020/ 1030/ 1040/ 1050/ 1060/ 1065/ 1070/ 1075/ 1080/ 1081/ 1090/1090ES/ 1200/ 1200T/ 1200US/ 1200XL/ 1200XL101/ 120XL102/ 1200XL103/1200XL104/ 1200XL105/ 1200XL106/ 1200XL109/ 1200XL110/ 1200XL111/1200L118/ 1200XL119/ 1200XL125/ 1200XL126/ 1200XL127/ 1200XL3/ 1200XL300/1200XL127/ 1200XL3/ 1200XL300/ 1200XL325/ 1200XL401/ 1200XL404/1200XL406/ 1200XL408/ 1200XL409/ 1200XL420/ 1200XL423/ 1200XL500/1200XL505/1200XL510/1200XL515/1200XL526/ 1201AP/ 1201Z/ 1207/ 1210/ 1214/ 1214SR/ 1215/ 1216/ 1220/ 1230/ 1232/ 1234/ 1235/ 1236/ 1237/ 1240/ 1242/ 1244/ 1245/ 1246/ 1247/ 1250/ 1266/ 1267/ 1270/ 1273/

Armada – 2940

Evo – N105/ N115/ N160/ N180/

C

FUJITSU-SIEMENS

Lifebook – N300 Series/ N5000 Series / N6000 Series

Toshiba

A60-S156/ A60-S1561/ A60-S159/ A60-S1591/ A60-S1591ST/ A60-S1592ST/A60-S166/ A60-S1661/ A60-S1662/ A60-S1691ST/ A65-S1062/ A65-S1063/A65-S1064/ A65-S1065/ A65-S1066/ A65-S1067/ A65-S109/ A65-S1091/A65-S126/ A65-S1261/ A65-S136/ A65-S1361/ A65-S1362/ A65-S1662/ A65-S1762/A70-S249/ A70-S2491/ A70-S2492ST/ A70-S256/ A70-S2561/ A70-S259/A70-S2591/ A70-S2362/ A75-S206/ A75-S2601/ A75-S2091/ A75-S211/ A75-S2111/ A75-S226/A75-S2261/A75-S229/A75-S2291/A75-S2293/ A75-S231/A75-S2311/A75-S276/ A75-S2761/ A75-S2762/ P25-S607/ P25-S608/ P25-S609/ P25-S670/ P25-S676/ P25-S6761/ P30-S6302ST/ P30-S6362ST/ P30-S701TD/P35-S609/ P35-S6091/ P35-S611/ P35-S6111/ P35-S629/ P35-S6291/ P35-S6292/P35-S631/ P35-S6311/ P35-S7012

D

ACER

TM345T/TM347T/TM3511TE/TM350TE/TM351TE/ TM352TE/ TM211T/ 212T/ 213TX/ TM340T/ TM341T/ TM342/ TM352TE-N/ TM353TE/ TM353TEV/ TM354TE/ TM354TEV/ TM521TE/ TM524TXV/TM525TE/ TM525TXV/ TM603TER/ TM604TER/ TM610TXV/ TM610TXVi/ TM610TXC/ TM611TXV/ TM611TXC/ TM612TXV/ TM612TXC/ TM613TXV/ TM613TXC/ TM730TX/ TM732T/ TM732TX/ TM734TL/ TM735TLV/ TM738TLV/ TM739TLV

E

ACER

Acer Travelmate – 200Series/ 200DX/ 200T/ 201/ 201T/ 202/ 202T/ 210/ 210TER/ 210TXF/ 211/ 211T/ 212/ 212T/ 212TE/ 212TXV/ 213/ 213T/ 213TX/ 213TXV/ 220/ 222Series/ 222Xseries/ 230/ 260/ 261/ 261XC/ 261XV/ 290/ 350/ 350TE/ 353TE-N/ 351/ 352/ 353/ 352TE/ 353TE/ 353TEV/ 354Series/ 354TE/ 354TEV/ 360/ 361/ 364Series/ 361Evi/ 364Eci/ 365/ 510/ 512/ 513/ 514/ 515/ 516/ 517/ 512DX/ 512T/ 512TE/ 512T-64/ 513DX/ 513T/ 514/ 514TXV/ 515TE/ 516TE/ 517TE/ 600Series/ 602/ 603/ 604/ 600TER/ 602TER/ 603TER/ 610/ 611/ 612/ 613/ 614Series/ 610TXC/ 610TXV/ 610Txi/ 611TXC/ 611TXCi/ 611TXV/ 612TXC/ 612TXCi/ 612TXV/613TXC 613TXCi/ 614TXVCi/ 620/ 621/ / 623Series/ 621Iv/ 621XC/ 621XV/ 623LC/ 623Lci/ 630/ 632/ 633/ 630XV/ 630Xci/ 632Xci/ 633Lci/ 660/ 720/ 722/ 723Series/ 720TX/ 720TXV/ 721TX/ 722ITX/ 722ITXW/ 722TX/ 723TX/ 723TXV/ 730/ 732/ 734/ 735Series/ 730T/ 730TX/ 730TXV/ 732TLV/ 732TX/ 732TXV/ 734TL/ 734TXV/ 735TLV/ 736/ 737/ 738/ 739Series/ 736TL/ 736TLV/ 737TLV/ 738TLV/ 739GTLV/ 739TLV/ 740/ 741/ 744/ 740LVF/ 741LVF/ 744LCF/ C300/ 8000

Acer TI & AcerNote – 330/330T/350C350E/350P/350PC/361/3680/386D/370C/374/500/509/ 850C/950/950C

Acer Aspire – 910/ 1200/ 1410/ 1640/ 1680/ 1690/ 2000/ 2010/ 2020/ 3000/ 3030/ 3500/3600/ 3610/ 3613/ 5000/ 5024/ 5030/ 5510/ 5920/ 9100/ 1414WLCi/ 2002Lci/1681LCi/ 6181WLMi/ 1683WLMi/ 1684WLMi/ 1685WLMi/ 2001LCi/ 2002LCi/2003LMi/ 2012WLCi/ 2012WLMi/ 2025WLMi/ 3002LC/ 3002LCi/ 3002LMi/3002WLCi/ 3002WLMi/ 3003WCi/ 3003WLCi/ 3003WLMi// 3022WLMi/ 3502LCi/3502NLCi/ 3502WLCi/ 3503WLCi/ 3602NWXM/ 3603NWXM/ 3603NWX-Mi/ 3603WXCi/ 3603WXMi / 3603XCi/ 3608NWXCi/ 3608WXMi/ 3603Xci 3614WLMi/ 3623MWXMi/ 3623WLCi/ 3623WLMi/ 3623WXCi/ 3623WXMi/ 3624WXCi/3624WXMi/ 5002LMi/ 5002WLMi/ 5514WXMi/ AS1690LCi/ AS1690WLCi/AS1690WLMi/AS169WLCi/AS1691WLMi/AS1692WLMi/AS1694WLMi/ ZL6

Acer TI Extenda – 700 Series/ 700T/ 710/ 711/ 712 Series/ 710DX/ 710T/ 710TE/ 711TE/ 712TE

Acer Tablet – TMC100Ti/ TMC104TCi/ TMC110TCi/ AS5920-6313

HP (Hewlett Packard)

Compaq Tablet PC – TC1000

F

AsusA2/ M2/ M3/ M5/ M6/ S5/ W3V/ W5V/ V6V/ Z3A/ Z33A/ Z71Vseries/ A1 Series/ A1000 series/ A1200 series/ A1300 series/ L8400 series/ F7 series/ F74 series/ F7000 series/ F7400 series/ L1 series/ L1000 series/ L1400 series/ L7 series/ L7000 series/ L7200 series/ L8 series/ M1 series/ M1000 series/ S1 series/ S1000 series/ S2 series/ S3 series/ S8200 series/ S8600 series/

NEC

Versa – LITEPAD/VX/

Gateway – Solo 1100/ 2100/ 2150/ 2200/ 2300/ 2300LS/ 2300XL/ 2500/ 2500LS/ 2500SE/2500XL/ 2550/ 5100/ 5100XL/ 5150LS/ 5150SE/ 5150XL/ 9100/ 9100LS/ 9100SE/9100XL/9150/9300/9300CX

HP (Hewlett Packard)

Pavilion – DV1600/ DV1610/ DV1610US/ DV1650/ DV1650US/ DV1670/ DV1670USHP/DV4000/ DV4000CTO/ DV4005/ DV4005US/ DV4010/ DV4015/ DV4015CL/DV4018/ DV4018CL/ DV4020/ DV4020us/ DV4030/ DV4030US/ V4030CA/ DV4040/DV4040CA/ DV4040US/ DV4100/ DV4100 CTO/ DV4125/ DV4125US/ DV4129/DV4129US/ DV4130/ DV4130US/ DV4150/ DV4150CA/ DV4150US/ DV4155/

Pavilion – DV4155CL/ DV4155US/ DV4165/ DV4165CL/ DV4170/ DV4170CA/DV4170US/ DV4200/ DV4210/ DV4217/ DV4217CL/DV4220/ DV4223/ DV4223CL/ DV4230/DV4230us/ DV4250/ DV4250US/ DV4250CA/ DV4253/ DV4253US/ DV4257/DV4257US/ DV4269/ DV4269US/ DV4270/ DV4270US/ DV4270CA/ DV4272/DV4272US/ DV4300/ DV4305/ DV4305US/ DV4307/ DV4307CA/ DV4307CL/DV4308/ DV4308WM/ DV4310/ DV4310US/ DV4320/ DV4320US/ DV4330/DV4330US/ DV4330CA/ DV4340US/ DV4340CA/ DV4400/ DV4401/ DV4420/DV5000/ DV50001/ DV5003/ DV5003CL/ DV5010/ DV5017/ DV5017CL/ DV5020/DV5020US/ DV5020CA/ DV5029/ DV5029US/ DV5030/ DV5030US/ DV5040/DV5040US/ DV5100/ DV5100CTO/ DV5110/ DV5110US/ DV5120/ DV5120US/DV5123/ DV5123CL/DV8000/ DV8000CTO/ DV80005/ DV8010/ DV8013/ DV8013CL/ DV8026ea/DV8040/ DV8040CA/ DV8040US/ DV8045/ DV8080/ DV8088/ DV8088US/ DV8100/ DV8110/ DV8110US/ DV8113/ DV8113CL/ DV8120/ DV8120US/ DV8120CA/DV8123/ DV8123CL/ DV8125/DV8125NR/ DV8130/ DV8130US/ DV8135NR/DV8140/ DV8140US/ DV8155/ DV8200/ DV8220Series/ZT3000/ ZT3001/ ZT3001US/ ZT3010/ ZT3010US/ ZT3015/ ZT3020/ ZT3020US/ ZT3025/ ZT3030/ ZT3040/ ZT3050/ ZT3068/ ZT3068CL/ ZT3101/ ZT3101US/ZT3110/ ZT3120/ ZT3130/ ZT3140/ ZT/3140US/ ZT3170/ ZT3170US/ ZT3200/ZT3201/ ZT3201US/ ZT3205/ ZT3210/ ZT3215/ ZT3220/ ZT3225/ ZT3230/ ZT3235/ZT3240/ ZT3241/ ZT3242/ ZT3250/ZT3250US/ ZT3260/ZT3280/ZT3280US/ZT3300/ ZT3301/ZT3301US/ ZT3302/ ZT3302/ ZT3302US/ ZT3305/ ZT3310/ ZT3340/ZT3340US/ ZT3349/Z T3349CL/ ZT3350/ ZT3350US/ ZT3355/ ZT3355US/ ZT3380/ ZT3380US/ ZT3400/ZE2000/ ZE2000CTO/ ZE2004/ ZE2004US/ ZE2005/ ZE2005US/ ZE/2008ZE2008WM/ ZE2010/ ZE2015/ ZE2015US/ ZE2020/ ZE2020CA/ ZE2100/ ZE2108/ ZE2108WM/ ZE2109/ ZE2109US/ ZE2110/ ZE2110US/ ZE2113/ ZE2113US/ZE2114/ ZE2114US/ ZE2115/ ZE2115US/ ZE2117/ ZE2117US/ ZE2120/ ZE2120CA/ZE2150/ZE2150US/ZE2200/ ZE2200CTO/ZE2300/ZE2308/ZE2308WM/ZE2309/ ZE2309NR/ ZE2315/ ZE2315US/ ZE2400/ ZE2401/ ZE2401XT/ ZE4900/ZE4901/ ZE4901us/ ZE4902/ ZE4903/ ZE4904/ ZE4905/ ZE4906/ ZE4907/ZE4908/ ZE4910/ ZE4910us/ ZE4911/ ZE4913/ ZE4915/ ZE4916/ ZE4917/ ZE4918/ZE4919/ ZE4920/ ZE4922/ ZE4923/ ZE4925/ ZE4926/ ZE4928/ ZE4929/ ZE4930/ZE4935/ ZE4940/ ZE4950/ ZE4951/ ZE4960/ ZE4980/

Compaq Business NoteBook – NC4000/NC4010/NC4200/NC6000/NC6100/NC6105/NC6110/ NC6115/NC6120/NC6200/NC6200CTO/NC6220/NC6230/NC7200/NC8000/NW8000/NX4800/ NX5000/NX5040/NX5100/NX6100/NX6105/NX6110/NX6115/NX6120/NX6125/NX7000/NX7010/ NX7040/NX7100/NX7200/NX9020/NX9030/NX9040/NX9050/(NOT FOR N900X/N9110)SeriesCompaq Business Mobile Workstation NW8000 Series

G

ACER

Aspire – Aspire 1300 / Aspire 1301XV / Aspire 1302LC / Aspire 1302LC / Aspire 1302XC / Aspire 1302XC / Aspire 1304LC / Aspire 1304XC / Aspire 1306 / Aspire 1306LC / Aspire 1307LC / Aspire 1310 / Aspire 1312 / Aspire 1314 / Aspire 1315 / Aspire 1350 / Aspire 1355LC / Aspire 1355LCi_ATI / Aspire 1355LM / Aspire 1355LMi_ATI / Aspire 1360 / Aspire 1400 / Aspire 1400LC / Aspire 1400XC / Aspire 1400XV / Aspire 1450 / Aspire 1500 / Aspire 1501LCe / Aspire 1501LCi / Aspire 1501LMi / Aspire 1610 / Aspire 1640 / Aspire 1640z / Aspire 1650 / Aspire 1680 / Aspire 1690 / Aspire 2000WLCi / Aspire 2000WLMi / Aspire 2630 / Aspire 3000 / Aspire 3400 / Aspire 3500 / Aspire 3610 / Aspire 3620 / Aspire 3680 / Aspire 3690 / Aspire 4000 / Aspire 4220 / Aspire 5000 / Aspire 5040 / Aspire 5050 / Aspire 5100 / Aspire 5500 / Aspire 5500z / Aspire 5510 / Aspire 5610 / Aspire 5630 / Aspire 5670 / Aspire 5684 / Aspire 7110 / Aspire 9400 / Aspire 9424 / Aspire 9520 / Aspire FR3200 /

Extensa – Extensa 2300 / Extensa 2350 / Extensa 3000 /

Ferrari – Ferrari 3000 / Ferrari 3200 / Ferrari 3400 /Travelmate – Travelmate 200 / Travelmate 2000 / Travelmate 2300 / Travelmate 2310 / Travelmate 2350 / Travelmate 240 / Travelmate 2410 / Travelmate 243 / Travelmate 244lc-XPP / Travelmate 250 / Travelmate 250p / Travelmate 252 / Travelmate 254ELCi / Travelmate 2600 / Travelmate 290 / Travelmate 290ATI / Travelmate 290E / Travelmate 3000 / Travelmate 3010 / Travelmate 3040 / Travelmate 3200 / Travelmate 3230 / Travelmate 3300 / Travelmate 370 / Travelmate 380 / Travelmate 4000 / Travelmate 4050 / Travelmate 4060 / Travelmate 4070 / Travelmate 4100 / Travelmate 4150 / Travelmate 4200 / Travelmate 4500 / Travelmate 4600 / Travelmate 4670 / Travelmate 4650 / Travelmate 505 to 508 series / Travelmate 5600 / Travelmate 600 series / Travelmate 6000 / Travelmate 8000 / Travelmate 8000 series / Travelmate 8100 / Travelmate C100 / Travelmate C110Ti / Travelmate C200 / Travelmate C300 / Travelmate Z9000

H

Samsung – A10/ M50/ M55/ M70/ M50LWM740/ M70 HWM 760/P10/ P20/ P25/ P50/ P60/ P10CXTC/ P25CXVC/ P25CXVZ/P25CXZC/ P25XTCB/ P25XVZ/ P25XZC/ P28/ P29/R65/ T10/ V20/ X20/ X25/X50/ X60/Sens 630/ Sens 820/ Sens 630/ Sens 820/ Sens Pro680/ Sens Pro850/ VM-6000/ SEMVC 740

Metro Book – MetroBook LT/ MetroBook VL/MPC (formerly MicronPC)TransPort/GX+/ GX2/ GX3 /LT/ VX/ XT/ XT2/ ZX

INFORMACJA O PRAWIDŁOWYM POSTĘPOWANIU W PRZYPADKU UTYLIZACJI URZĄDZEŃ ELEKTRONICZNYCH I ELEKTRYCZNYCH

Umieszczony na naszych produktach symbol przekreślonego kosza na śmieci informuje, że nieprzydatnych urządzeń elektrycznych czy elektronicznych nie można wyrzucać razem z odpadami gospodarczymi.

Właściwe działanie w wypadku konieczności utylizacji urządzeń czy podzespołów lub ich recyclingu polega na oddaniu urządzenia do punktu zbiórki, w którym zostanie ono bezpłatnie przyjęte. W niektórych krajach produkt można oddać podczas zakupu nowego urządzenia.

Prawidłowa utylizacja urządzenia daje możliwość zachowania naturalnych zasobów Ziemi na dłużej i zapobiega degradacji środowiska naturalnego. Informacje o punktach zbiórki urządzeń wydają właściwe władze lokalne.

Nieprawidłowa utylizacja odpadów zagrożona jest karami przewidzianymi prawem obowiązującym na danym terenie.

MANTA®

Dział Obsługi Klienta
tel: +48 22 332 34 63 lub e-mail: serwis@manta.com.pl
od poniedziałku do piątku w godz. 9.00-17.00

Producent zastrzega sobie możliwość wprowadzenia zmian w specyfikacji produktu bez uprzedzenia.

RoHS

Made in P.R.C.
FOR MANTA EUROPE